User's Manual

SAFETY INSTRUCTIONS


- 1. Make sure your battery has enough voltage for the controller to
- recognize the battery type before first installation.

 2. The battery cable should be as short as possible to minimize loss
- 3. The regulator is only suitable for lead acid batteries: OPEN. AGM. GEL it is not suited for nickel metal hydride, lithium ions or other batteries.
- 4. The charge regulator is only suitable for regulating solar modules. Never connect another charging source to the charge regulator.

PRODUCT FEATURES

- 1.Build-in industrial micro controller.
- 2. Big LCD display, all adjustable parameter.
- 3.Fully 3-stage PWM charge management.
- 4.Build-in short-circuit protection, open-circuit protection, reverse protection, over-load protection.
- 5. Dual USB output, the maximum current of 2.5A, to support Apple's mobile phone charging.
 6. Dual mosfet Reverse current protection, low heat production.

LCD DISPLAY/KEY



MENU: Switch between different display or to enter/exit setting by long press.

Un :press to increase value.


DOWN: Press to decrease value

SYSTEM CONNECTION


- 1.connect the battery to the charge regulator-plus and minus.
- 2. Connect the photovoltaic module to the regulator-plus and minus.
- 3. Connect the consumer to the charge regulator-plus and minus.

The reverse order applies when deinstalling!

An improper sequence order can damage the controller!



LCD DISPLAY/SEETING



[RBL01B]

- 1.Press the [DOWN] button to ON/OF load manully at main display 2.The work mode is working as below.
- [24H] load output 24 hours [1-23H] load on after sunset and dosed after setting hours [OH] Dusk to dawn

TROUBLE SHOOTING

Situation	Probable cause	Solution
Charge icon not on when sunny	Solar panel opened or reversed	THE COMMENT
	Mode setting wrong	Set again
	Battery low	Recharge
Load icon slow	Over load	Reduce load watt
flashing	Short circuit prolection	Remove short circuit, 1 minutes or so automatic recovery
Power off	Battery too low/ reverse	Check battery/connection

TECHNICAL PARAMETER

MODEL	Kw1210	Kw1220	Kw1230	
Batt voltage	12V/24V auto			
Charge current	10A	20A	30A	
Discharge current	10A	10A	10A	
Max solar input	12V battery, the highest 23V; 24V battery when the highest 46V			
F	B1 sealed	B2 gel	B3 flood	
Equalization	14.4V	14. 2V	14.6V	
Float charge	13.7V (defaul,adjustable)			
Discharge stop	10.7V (defaul,adjustable)			
Discharge reconnect	12.6V(defaul,adjustable)			
Charge reconnect	13V			
Voltage of open light	Solar panel 8V(Light lights delay)			
Voltage of close light	Solar panel 8V(Light off delay)			
USB output	2 way USB output, 5V/2.5A(MAX)			
Self-consume	<10mA			
Operating temperature	-35 ∼ +60C	•		
Size/Weight	133.5 * 70 * 35mm / 165g			

- *All red color voltage x2 while using 24V system
- *This instruction is a general manual, such as a slight difference
- *Product specifications are subject to change without prior notice